



TRAVEL TEE DLX

GETTING STARTED



Thank you for choosing the SKLZ Travel Tee DLX. We are dedicated to providing you with the best tools and instruction possible to help you prepare for your sport. If there is anything else we can do to help, don't hesitate to send us an email at customerservice@sklz.com or give us a call at **1-877-225-7275**.

BEFORE YOU BEGIN:

- Read all instructions carefully before using. If the instructions are not followed correctly, it could result in injury or damage to the product.
- Always check for wear and tear before use. If any is found, do not use the product.
- If you are missing any Travel Tee DLX components, please contact SKLZ customer service toll free at **1-877-225-7275**.
- Adult assembly is recommended.

⚠️WARNING:

PHYSICIANS' WARNING: Not all exercise equipment and programs are suitable for everyone. It is recommended that you consult your physician before using this equipment or beginning this or any other exercise program.

- Not suitable for children under 3 years of age.
- When using your Travel Tee DLX, please have others stay clear of the hitting area to reduce the risk of injury.
- Do not store in extremely high or low temperatures to avoid damaging or reducing the life of your Travel Tee DLX.
- Do not leave your Travel Tee DLX outdoors for extended periods of time.
- Always wear a NOCSAE-approved helmet. Face guard recommended.

⚠️CAUTION:

- When in use, make sure your Travel Tee DLX is in a clear area to avoid damage to property.
- When using the Travel Tee DLX with a net, position the tee far enough away to allow the batter to swing freely, while still being close enough to ensure the net will capture a hit ball.

PATENT PENDING

IDEA SUBMISSION


If you have an idea for a new and innovative sport training product, visit sklz.com to submit your concept. Some restrictions may apply.

1-YEAR LIMITED WARRANTY


This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email customerservice@sklz.com or call toll free 1-877-225-7275.**

Made in China. ©2016 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008, USA. SKLZ is a registered trademark of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

IN THE BOX




GETTING STARTED




1. Push the legs down on the base (E) until they are fully extended, and then tighten the butterfly knob to lock in place.

WARNING:

Keep fingers and hands away from opening between legs and adjustment bracket to avoid pinching or injury.




2. Fit the dual-wrapped tee top (A) onto the top of the main pole (B), with the tee cup pointing upward. The neck should slide to fit snugly in the main pole.




3. Slide the main pole into the base pole (D).

ADJUSTING HEIGHT

Height can be adjusted on the main and base pole.



1. To adjust the height of the base pole, slide the main pole up or down, and then lock in place by tightening the adjustment lock.



2. Adjust the height of the funnel top by pulling it up or down within the main pole.